BONACCORD (Cord Drawn) BRACKETS

From wall to centre of rod (BonAccord) - 58mm

Screw - 7mm from top of bracket plate to screw centre

Bracket
Base Plate
Length - 50mm
Width - 30mm

From top screw centre to
top of glide hole - 31mm

Screw - 7mm from bottom of
bracket plate to screw centre

BonAccord Single Bracket (Visible Fixing)

From wall to centre of rod (BonAccord) - 67mm

Screw - 15mm from top of concealed plate to top of adjustment slot for screw

Bracket
Base Plate
Length - 58mm
Width - 35mm

Concealed Base Plate
has 25 - 30mm adjustment

Screw
15mm from bottom of
concealed plate
(Bottom of adjustment
slot for screw)

From top of concealed plate to
top of glide hole - 44mm

BonAccord Single Bracket (CONCEALED)

From wall to centre of rod (BonAccord) -150mm (back rod adjustable to suit)

Screw - 7mm from top of bracket plate to screw centre

Bracket
Base Plate
Length - 50mm

7mm

From top screw hole to
glide centre (BonAccord) -31mm

From top screw hole to
glide centre (25mm back Rod) - 63mm

Therefore rear curtain sits 32mm lower than front curtain

**BonAccord Double Bracket
BonAccord Front / 25mm Back**

From wall to centre of rod (BonAccord) - 150mm (back rod adjustable to suit)

Screw - 7mm from top of bracket plate to screw centre

Bracket
Base Plate
Length - 50mm

7mm

From top screw hole to
glide centre (16mm back Rod) - 55mm

From top screw hole to
glide centre (BonAccord) -31mm

Therefore rear curtain sits 24mm lower than front curtain

**BonAccord Double Bracket
BonAccord Front / 16mm Back**